

Issue	Possible Cause	Possible Solution
How do I field calibrate my unit?		1. Page 4-5 in the manual (step by step instructions)
The reading appears noisy or inaccurate	1. The sensor is dirty	1. Fill the sensor with a liquid that is a solvent for the contaminant. 1. I.e. Ether is often effective for some oils. 2. Completely dry and flush with a volatile solvent to ensure that the tube is dry before installation (review page 4 of manual).

If none of these steps help alleviate the issues, please contact sales@lesker.com with the Troubleshooting form as well as provide the R&D and Resistance Values (see Error Message - EMIS FAIL for instructions on how to obtain these values)