

Issue	Possible Cause	Possible Solution
The reading appears very different from expected pressure	<ol style="list-style-type: none"> 1. Gauge is contaminated 2. Calibration is needed 	<ol style="list-style-type: none"> 1. Perform the "Self Test Operation" from the manual. If "Self Test" determines the gauge to be "not good", replace the gauge tube. 2. Calibrate the gauge follows the Calibration Instructions from the manual.

If none of these steps help alleviate the issues, please contact sales@lesker.com with the Troubleshooting form as well as provide the R&D and Resistance Values (see Error Message - EMIS FAIL for instructions on how to obtain these values)